

880-8 White Motor(not shown)

880-6 Discharge Check Valve Body




880-4 Check Valve "O" Ring



880-11 Discharge Disc w/Spring



880-10 Discharge Valve Seat



880-17 Discharge seat "O" Ring



880-2 Outer "O" Rings (2)



880-7 Bearing with Offset



880-19 Pump Head Saddle



880-21 1/4 x 20 x 1" SS Cap Screws (3)



880-20 Piston Guide Block



880-21 1/4 x 20 x 1" SS Cap Screws (2)

880-13 Pump Head



880-3 Retainer



880-12 Suction Valve Seat w/Spring/Retainer



880-16 High Pressure Seal



880-15 Internal "O" Ring



880-1 Seal Guide



880-9 Piston Assembly



880-18 Back Bone (Ssingle head)



880-21 1/4 x 20 x 1" SS Cap Screws (4)



880-14 Cover Plate



880-4 Check Valve "O" Ring



880-5 Suction Check Valve Body

